

HG®

kitchen

Power gel brush oven cleaner

Removes burnt-in food and
grease

Thoroughly clean, effortless results



483/06 2512

HG power gel brush oven cleaner

- powerful, highly adhesive gel formula
- with a brush for precise and controlled application
- easy to use

With its powerful, highly adhesive gel formula, *HG power gel brush oven cleaner* thoroughly removes the most stubborn, caked-on grease and burnt bits. Including from vertical surfaces, such as the walls of the oven. The built-in brush head makes controlled and accurate application, including on difficult to reach places, extremely easy. Also extremely suitable for baking sheets, grills and barbecues.

Attention: Transport and store the bottle upright. Do not use this product on warm or varnished surfaces, aluminium, copper, bronze, cast iron, or the outside of the oven, grill or barbecue. Not suitable for appliances with a non-stick coating or a self-cleaning function. Before use, check the instructions for your appliance first. Prevent the gel from running onto sensitive surfaces, such as plastic, wood, composite, etc. Should this happen accidentally, clean immediately with plenty of water.

Medical personnel can request the data sheet via +31 36 54 94 777
The consumer's information sheet can be obtained via www.HG.eu

Directions: see inside

0548300302506 2512



8 711577 304317

DANGER



Made in
The Netherlands by
HG International b.v.,
P.J. Oudweg 41, 1314 CJ
Almere, The Netherlands,
Tel.: +31 36 54 94 700

UFI: 8NG0-YNPQ-180F-F15P

UK importer: HG UKI Ltd, Weston Business
Centre, Parsonage Road, Takeley, Essex,
CM22 6PU. Tel.: +44 (0) 1206 822 744




HG power gel brush oven cleaner

DANGER H290- May be corrosive to metals. **H314-** Causes severe skin burns and eye damage. **P101-** If medical advice is needed, have product container or label at hand. **P102-** Keep out of reach of children. **P234-** Keep only in original packaging. **P280-** Wear protective gloves and eye protection. **P301+P330+P331-** IF SWALLOWED: rinse mouth. Do NOT induce vomiting. **P303+P361+P353-** IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water [or shower]. **P305+P351+P338-** IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. **P310-** Immediately call a POISON CENTER or doctor/physician. **P501-** Dispose of contents and container in accordance with all local, regional, national and international regulations. contains: sodium hydroxide CAS: 1310-73-2 <5% non-ionic surfactants; perfumes

HG power gel brush oven cleaner

Directions:



Shake the bottle well.
Screw off the cap.




Hold the bottle upside down
to apply the gel.



Depending on the amount of dirt,
wipe off the gel after a maximum
3 hours and finally remove any
residue with plenty of water.



Rinse the brush clean after use.



After cleaning, screw the cap
back onto the bottle.

DANGER



Made in The
Netherlands by
HG International b.v.,
P.J. Oudweg 41, 1314 CJ
Almere, The Netherlands,
Tel.: +31 36 54 94 700

UFI: 8NG0-YNPQ-180F-F15P

UK importer: HG UKI Ltd, Weston Business
Centre, Parsonage Road, Takeley, Essex,
CM22 6PU. Tel.: +44 (0) 1206 822 744

0548300302506 2512