

HG®

LAUNDRY ROOM

WASHING MACHINE CLEANER AND ODOUR FRESHENER

removes dirt and
soap deposits

550 g e

HG washing machine cleaner and odour freshener

- removes dirt and soap deposits
- for a clean and fresh washing machine
- sufficient for 3 treatments


Washing machines do not always smell fresh and at times the smell gets really bad. Grease deposits and the remnants of liquid or powder detergents in the drains, on the filters and rubbers are the cause. *HG washing machine cleaner and odour freshener* cleans the entire washing machine extremely effectively and produces a clean and fresh washing machine.

Directions for use: Make sure there is no laundry in the washing machine. Use a measuring cup to add 165 gram (approx. 150 ml) *HG washing machine cleaner and odour freshener* to the main detergent tray. Rinse the measuring cup properly after use. Do not add any detergent. Set the programme to dark laundry at 60°C, without a pre-wash. Switch on the washing machine and let the programme complete without interruptions, including spinning. Recommended frequency: 1x every 4 weeks or more often if required.

Attention: If the washing machine continues to smell after using this product, or the smell returns within 1 or 2 days, we recommend cleaning it thoroughly with *HG washing machine and dishwasher deep clean and service*. By using *HG washing machine and dishwasher deep clean and service* 1x every 3 months, you prevent wear and tear to the components and malfunctioning of the washing machine.

Medical personnel can request the data sheet via +31 36 54 94 777

The consumer's information sheet can be obtained via www.HG.eu



0565702105506
2411

Products and tips? See:

HG.EU

Consumer Services?
Call: +44 (0)1279 598360



contains e.g.:

oxygen bleaching agent

> 30%

perfume

DANGER H314- Causes severe skin burns and eye damage. **P101-** If medical advice is needed, have product container or label at hand. **P102-** Keep out of reach of children. **P280-** Wear protective gloves and eye protection. **P303+P361+P353-** IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water [or shower]. **P305+P351+P338-** IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. **P501-** Dispose of contents and container in accordance with all local, regional, national and international regulations. Contains Sodium percarbonate, CAS: 15630-89-4 and sodium hydroxide CAS: 1310-73-2.



Made in The Netherlands by
HG International b.v., P.J. Oudweg 41,
1314 CJ Almere, The Netherlands,
Tel.: +31 36 54 94 700

UFI: MJJP-4VP7-A10P-TDTA

HG Does what is promises.

UK importer: HG UKI Ltd,
Weston Business Centre, Parsonage Road, Takeley,
Essex, CM22 6PU. Tel.: +44 (0) 1206 822 744