

# HG®

outdoors

## Garden furniture cleaner

Removes stubborn dirt and grime

Garden furniture looks like new  
Safe for all garden furniture



### HG garden furniture cleaner

- extremely powerful
- for all types of garden furniture

*HG garden furniture cleaner* effortlessly removes stubborn stains from plastic, aluminium, woven cane (look), pulp cane, polywood and metal garden furniture, as well as from epoxy, galvanised and most other (combinations of) materials.

**Directions for use:** Turn the nozzle on the front side a quarter. Spray the surface area to be cleaned and leave to soak for one to two minutes. Remove dirt with a cloth or kitchen roll. For very stubborn stains, leave to soak a little longer. Remove dirt with a brush or a pad and rinse. Turn the nozzle a quarter after use (OFF).

**Attention: Transport and store the bottle upright.** For maintenance of your (hard) wood garden furniture, please refer to our extensive product range for hardwood products.

Medical personnel can request the data-sheet via +31 36 54 94 777  
The consumer's information sheet can be obtained via [www.HG.eu](http://www.HG.eu)



0512401105006  
2510

Products and tips? See:

**HG.EU**

Consumer Services?  
Call: +44 (0)1279 598360

**P101-** If medical advice is needed, have product container or label at hand. **P102-** Keep out of reach of children. contains a.o.: < 5% non-ionic and anionic surfactants, phosphates; preservation agents: 2-bromo-2-nitropropane-1,3-diol

Made in The Netherlands by HG International b.v., P.J. Oudweg 41, 1314 CJ Almere, The Netherlands, Tel.: +31 36 54 94 700

50% RECYCLED PLASTIC BOTTLE

UK importer: HG UKI Ltd,  
Weston Business Centre, Parsonage Road,  
Takeley, Essex, CM22 6PU  
Tel.: +44 (0) 1206 822 744