

CC09911-A

HG BATHROOM

SILICON SEAL REMOVER

removes even the worst sealant

100 ml e

HG silicon seal remover

- removes even the worst sealant
- works within 15 minutes
- does not affect other materials
- includes brush and spatula

Before proceeding to apply a new silicon joint, it is important to completely remove the remains of the previous joint in order to obtain a totally impermeable result. This is an unpleasant task which takes time. *HG silicon seal remover* will remove old seals quickly and easily. *HG silicon seal remover* has been specially developed to remove silicon seals from surfaces such as: stainless steel, enamel, various sorts of plastic, ceramic, sealed or non-porous natural stone and other similar materials. *HG silicon seal remover* has a pleasant odour, is easy to apply and will not damage the surfaces mentioned above. Traces of numerous other sorts of seals such as acrylic, butylene and universal seals can also be removed with *HG silicon seal remover*.

Made in The Netherlands by
HG International b.v.
P.J. Oudweg 41,
1314 CJ Almere, The Netherlands
Tel.: +31 36 54 94 700

UK importer: HG UKI Ltd,
Weston Business Centre, Parsonage
Road, Takeley, Essex, CM22 6PU.
Tel.: +44 (0) 1206 822 744

UFI: CMKW-KTTS-V007-SUW5

HG Does what it promises.

HG BATHROOM

SILICON SEAL REMOVER

removes even the worst sealant

100 ml e

HG silicon seal remover

- removes even the worst sealant
- works within 15 minutes
- does not affect other materials
- includes brush and spatula

Directions for use: First remove as much of the old seal as possible, using a knife to cut it away from the edge of the surface to be treated. Any adjoining areas of seal should be protected with adhesive tape. Apply *HG silicon seal remover* liberally using the brush provided. Allow 15 minutes for *HG silicon seal remover* to work. Once the seal has loosened remove with the spatula provided. If there is some resistance, leave the product to work for a few minutes more. Finally remove the last traces of *HG silicon seal remover* by rinsing with clear water using a cloth or nail brush if necessary to remove any last traces. Repeat the treatment if necessary. Allow the surface to dry completely before re-applying a seal.

Coverage:

100 ml will treat at least 10 to 15 metres.

Attention: Transport and store the box upright. We recommend to test *HG silicon seal remover* in a small and inconspicuous place first. Do not use on porous materials. Before treating a new silicon seal, make sure that the surface is completely dry. **P101-** If medical advice is needed, have product container or label at hand. **P102-** Keep out of reach of children.

Medical personnel can request the data sheet via +31 36 54 94 777

The consumer's information sheet can be obtained via www.HG.eu

0629001101006
2409

Products and tips? See:
HG.EU
Consumer Services?
Call: +44 (0)1279 598360

