

## HG artificial floor treating matrix

# HG®

floors

## Vinyl protector



Protect

P77

Protects against scratching and wear  
Adds a satin shine

1000 ml e

**Attention: Transport and store the bottle upright.**  
Keep in a frost-free area.

Medical personnel can request the data sheet via  
+31 36 54 94 777

The consumer's information sheet can be obtained  
via [www.HG.eu](http://www.HG.eu)

**EUH208-** Contains triisobutyl phosphate, Rosin, fumarated, polymer with glycerol, ammonium salt. Might cause allergic reactions. **P101-** If medical advice is needed, have product container or label at hand. **P102-** Keep out of reach of children. Contains: <5% phosphates, non-ionic surfactants; preservation agents: Benzisothiazolinone

Made in The Netherlands by  
HG International b.v.,  
P.J. Oudweg 41, 1314 CJ Almere,  
The Netherlands, Tel.: +31 36 54 94 700

50% RECYCLED PLASTIC BOTTLE

UK importer: HG UKI Ltd,  
Weston Business Centre, Parsonage Road, Takeley,  
Essex, CM22 6PU. Tel.: +44 (0) 1206 822 744



8 711577 009342 >

0511301210006 2601

Products and tips? See:

**HG.EU**

Consumer Services?  
Call: +44 (0)1279 598360

# HG vinyl protector (product 77)

- adds shine

**HG vinyl protector** is a unique, easily applicable liquid polymer emulsion which forms a glossy super-thin, yet extremely strong protective film when dry. It protects artificial flooring such as vinyl, linoleum, marmoleum, PVC and resin floors against wear, scratching and other damage. This protective film also masks existing worn patches and gives an anti-slip effect.

## Directions:

1. The floor, also new artificial flooring, must be completely clean and free of grease and dust. Remove any old wax, polish and polymer layers. For the treatments that may be required: see the HG artificial floor treating matrix on the side of this bottle.
2. Preferably apply with a wax applicator for even application (see the picture on the front of this bottle). It is also possible to use a lint-free, clean (tea) towel wrapped around a squeegee.
3. Do not shake before use, pour the liquid undiluted over the floor and then apply evenly in one direction without putting pressure on the wax applicator or squeegee.
4. Once the product has dried (after about 60 minutes), a second layer can be applied crosswise onto the first layer.
5. The floor can be walked on about 1 to 2 hours after the final treatment and has completely hardened after 3 days.

**Coverage:**  $\pm 40 \text{ m}^2$  per litre per layer.

**Tip:** When necessary in walkways where the protective film is more liable to wear, a new protective film can be quickly and easily applied over the existing film.

**Attention:** If this product is used on a click-system floor, check first whether the interlayer is 100% synthetic. If it is not, do not use this product because the interlayer could start to swell. Do not use in rooms that may be damp, such as bathrooms.

