



laundry room

Descaler for appliances

Powerful limescale-removing action

Extends machine life

Safe for any hot water appliance



HG descaler for appliances

• extends your machine's lifespan

A descaling liquid that has been developed especially for removing limescale from hot-water equipment.

Washing machines: In soft-water areas, add 100 ml of product to the detergent tray, add 200 ml in hard-water areas. Run the shortest programme with a temperature of 60°C. Halfway through the programme, switch off the machine, leave the product to work for approximately 20 minutes and then complete the programme.

Heating elements: (Not for electric kettles) can be treated separately too. Brush on *HG descaler for appliances* with a brush, leave it to absorb for a little while and then remove the limescale with a soft sponge. Then rinse thoroughly with plenty of water.

Coffee makers: Dilute 50 ml product with 500 ml water and pour this carefully into the electric kettle. Leave the machine to work as if you're making coffee. Carefully pour away the solution. If the machine does not percolate properly, repeat the treatment with a new mixture. Finally, clean the machine 3 times with hot water to ensure no limescale or unwanted tastes remain.

Electric kettles: Dilute 50 ml product with 500 ml cold water and pour this carefully into the electric kettle. Do not switch on the kettle. Leave the liquid in the kettle for around 40 minutes and then pour it out carefully. Repeat the treatment if required. Then rinse the kettle 3x with plenty of warm water.

contains a.o.:

preservation agents: formaldehyde



0517400105006
2511

Products and tips? See:
HG.EU
Consumer Services?
Call: +44 (0)1279 598360

Attention: Transport and store the bottle upright.
Always consult the instructions for your machine before using *HG descaler for appliances*. Do not use in pod-coffee machines and on surfaces that are sensitive to acids, such as aluminium, zinc or enamel. Never use a descaler for steam irons; that includes *HG descaler for appliances*. Limescale affects the heating element. Therefore you should descale your hot-water equipment regularly, to ensure that limescale does not affect your element.

Medical personnel can request the data sheet via +31 36 54 94 777

The consumer's information sheet can be obtained via www.HG.eu

DANGER H314- Causes severe skin

burns and eye damage. **P101-** If

medical advice is needed, have

product container or label at

hand. **P102-** Keep out of

reach of children. **P280-** Wear

protective gloves and eye

protection. **P301+P330+P311-** IF

SWALLOWED: rinse mouth. Do NOT

induce vomiting. **P303+P361+P353-**

IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water [or shower]. **P305+P351+P338-** **IF IN EYES:** Rinse

cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. **P501-** Dispose of contents and container in accordance with all local, regional, national and international regulations. Contains glycolic acid

EINECS: 201-180-5

Made in The Netherlands by HG International b.v.,
P.J. Oudweg 41, 1314 CJ Almere
The Netherlands, Tel: +31 (0)36-5494700

UFI: VN9J-QGTG-J00U-HJT

50% RECYCLED PLASTIC BOTTLE

UK importer: HG UKI Ltd, Weston Business Centre,
Parsonage Road, Takeley, Essex, CM22 6PU.
Tel: +44 (0) 1206 822 744

